Channel 1

Mode	*DMX Mode*	*Sound 2 Light*
DMX Adress	*0*	*255*

Channel 2

Color	*OFF*	*Red*	*Green*	*Blue*	*White*
DMX Adress	*0*	*12*	*22*	*32*	*46*

Color	*Yellow*	*R+G*	*R+B*	*R+W*	*R+Y*
DMX Adress	*50*	*60*	*70*	*80*	*90*

Color	*B+G*	*G+W*	*Y+G*	*B+W*	*B+Y*
DMX Adress	*100*	*110*	*120*	*130*	*140*

Color	*Y+W*	*R+G+B*	*R+G+W*	*R+G+Y*	*G+B+W*
DMX Adress	*150*	*160*	*170*	*180*	*190*

Color	*G+Y+B*	*R+G+B+W*	*R+G+B+Y*	*G+B+Y+W*	*R+G+B+Y+W*
DMX Adress	*200*	*210*	*220*	*230*	*240*

Channel 3

[Fadeable]

Mode	*Strobe OFF*	*Strobe High*
DMX Adress	*0*	*255*

Channel 4

[Fadeable]

Mode	*LED's OFF*	*Dimmer High*
DMX Adress	0	255