• If the equipment has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation might damage the equipment. Leave the equipment switched off until it has reached room temperature.

• If your product fails to function correctly, discontinue use immediately. Pack the unit securely (preferably in the original packing material), and return it to your dealer for service.

• Only use fuses of same type and rating.

• Repairs, servicing and power connection must only be carried out by a qualified technician. THIS UNIT CONTAINS NO USER SERVICEABLE PARTS.

• WARRANTY; One year from date of purchase.

OPERATING DETERMINATIONS

If this equipment is operated in any other way, than those described in this manual, the product may suffer damage and the warranty becomes void.

Incorrect operation may lead to danger e.g.: short-circuit, burns, electric shocks, lamp failure etc.

Do not endanger your own safety and the safety of others!

Incorrect installation or use can cause serious damage to people and property.

FUNCTIONS AND OPERATION:

1. DMX 512 SUMMARY

This unit obtains 2 DMX channels and can match to use with any international standard DMX512 controller.

CH1: STROBE (speed) CH2: DIMMER (0-100%)

2. Function set-up (DMX address setting)

FUNCTION SET UP

10	9-2	1	FUNCTION
OFF	ADDRESS		DMX512 Control
ON	NO USE	OFF	Speed and Dimmer
ON	NO USE	ON	Line and Dimmer

Maintenance:

Always disconnect the electric mains power supply before cleaning or servicing. Damages caused by non-observance are not subject to warranty.

The DMX Strobe requires almost no maintenance. However, you should keep the unit clean.

Wipe the cover with a damp cloth.

Do not immerse in liquid.

Do not use alcohol or solvents

Make sure the equipment is fully dry before re-connecting to the mains.

WARNING!

Disnnect from power before servicing
Lamp and fixture may extremely hot
Let cool before handling