

USB TO DMX Interface Control Cable Install Software Test Guide:

Step 1 : Connect your PC (USB) to XLR 3PIN Input Port (LED moving light device)



Step 2: Generally speaking, Win8/Win10 will recognize the serial com port .

If you can not find the serial port (do not recognize it) , please go to FTDI website
or use our Mini CD to intall the FTDI Chipset Driver . .

Web Shop
Newsletter
Corporate
Contact Us

are disclaimed. In no event shall future technology devices international limited be liable for any direct, indirect, incidental, special, exemplary, or consequential damages (including, but not limited to, procurement of substitute goods or services, loss of use, data, or profits, or business interruption) however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the use of this software, even if advised of the possibility of such damage.

FTDI drivers may be used only in conjunction with products based on FTDI parts.

FTDI drivers may be distributed in any form as long as license information is not modified.

If a custom vendor ID and/or product ID or description string are used, it is the responsibility of the product manufacturer to maintain any changes and subsequent WHCK re-certification as a result of making these changes.

For more detail on FTDI Chip Driver license terms, please [click here](#).



Currently Supported VCP Drivers:

Operating System	Release Date	Processor Architecture							Comments
		x86 (32-bit)	x64 (64-bit)	PPC	ARM	MIPSII	MIPSV	SH4	
Windows*	2017-08-30	2.12.28	2.12.28	-	-	-	-	-	WHQL Certified. Includes VCP and D2XX. Available as a setup executable. Please read the Release Notes and Installation Guides.
Linux	-	-	-	-	-	-	-	-	All FTDI devices now supported in Ubuntu 11.10, kernel 3.0.0-19. Refer to TN-101 if you need a custom VCP VID/PID in Linux. VCP drivers are integrated into the kernel.
Mac OS X 10.3 to 10.8	2012-08-10	2.2.18	2.2.18	2.2.18	-	-	-	-	Refer to TN-105 if you need a custom VCP VID/PID in MAC OS.
Mac OS X 10.9 and above	2017-05-12	-	2.4.2	-	-	-	-	-	This driver is signed by Apple.
Windows CE 4.2-5.2**	2012-01-06	1.1.0.20	-	-	1.1.0.20	1.1.0.10	1.1.0.10	1.1.0.10	
Windows CE 6.0/7.0	2016-11-03	1.1.0.22 CE 6.0 CAT CE 7.0 CAT	-	-	1.1.0.22 CE 6.0 CAT CE 7.0 CAT	1.1.0.10	1.1.0.10	1.1.0.10	For use of the CAT files supplied for ARM and x86 builds refer to AN_319.
Windows CE 2013	2015-03-06	1.0.0	-	-	1.0.0	-	-	-	VCP Driver Support for WinCE2013


*Includes the following version of the Windows operating system: Windows 7, Windows Server 2008 R2 and Windows 8, 8.1, Windows server 2012 R2, Windows Server 2016 and Windows 10. Also, as Windows 10 IoT.

Step 3 : Download the freestyler software


Download website: www.freestylerdmx.be



And then we can choose the latest release version 3.6.49 . and click the button "here" to download.




Step 4: Install the freestyler software




If there are shows some error when you installing , you can choose the “ignore” to continue .


Step 5: Open the freestyler software (details see the vedio) .



Step 6: Set or add the Light as in picture



Step 7: Rotate the LED Moving light



Step 8 : FOR More functions , Would you please let your Profession Light Control engineer to set it .

Welcome to leave best review and 5-star feedback . thank you !