

Giant Mamba Mini Washer

- nur 14 Kanalmodus -

Channel	Value	Function
1		Pan - Movement 8 bit
	0 - 255	Pan - Movement
2		Pan - Fine 16 bit
	0 - 255	Fine control of Pan movement
3		Tilt - Movement 8 bit
	0 - 255	Tilt - Movement
4		Tilt - Fine 16 bit
	0 - 255	Fine control of Tilt movement
5		Speed Pan / Tilt movement
	0 - 225	max to min speed
	226 - 255	no funktion
6		RED - LED
	0 - 255	Red (0-Black, 255-100% Red)
7		GREEN - LED
	0 - 255	Green (0-Black, 255-100% Green)
8		BLUE - LED
	0 - 255	Blue (0-Black, 255-100% Blue)
9		WHITE - LED
	0 - 255	White (0-Black, 255-100% White)
10		Shutter / Strobe
	0 - 31	LED off
	32 - 63	LED on
	64 - 95	Strobe effect slow to fast
	96 - 127	LED on
	128 - 159	Pule Strobe effect slow to fast
	160 - 191	LED on
	192 - 223	Random Strobe effect slow to fast
	224 - 255	LED on
11		Dimmer Intensity
	0 - 255	Intensity 0 to 100%
12		Rainbow
	0 - 4	no funktion
	5 - 29	R
	30 - 54	G
	55 - 79	B
	80 - 104	W
	105 - 129	Rainbow Colours
	130 - 154	Rainbow Colours
	155 - 174	Rainbow Colours
	175 - 179	Rainbow Colours
	180 - 184	Rainbow Colours
	185 - 189	Rainbow Colours
	190 - 210	Rainbow Colours
	211 - 255	Crossfading colours from slow to fast

13		ZOOM Movement 8 bit
	0 - 255	ZOOM Movement
14		Reset, Internal Programms
	0- 79	Normal
	80 - 99	All motors reset
	100 - 119	Internal Programm 1 (scene 1-8 of EEPROM)
	120 - 139	Internal Programm 2 (scene 9-16 of EEPROM)
	140 - 159	Internal Programm 3 (scene 17-24 of EEPROM)
	160 - 179	Internal Programm 4 (scene 25-32 of EEPROM)
	180 - 199	Internal Programm 5 (scene 33-40 of EEPROM)
	200 - 219	Internal Programm 6 (scene 41-48 of EEPROM)
	220 - 239	Internal Programm 7 (scene 49-56 of EEPROM)
	240 - 255	Music Control (scene of Programm 1)