

flash(FS00-FS99), fading time(Fd00-Fd99), running speed(SP00-SPFL).

When it is Pz1 and Pz2, you can set the background color and chasing color for this effect, switch it from 1-1 (background color) to 2-1 (chasing color) by "SETUP", adjust different colors by "UP" "DOWN".

2. Auto run mode

You can press "MODE" button to select auto run mode, it shows **Run TL**, then it will run the built-in programs automatically.

Press "SETUP", it shows n. 001, then you can adjust the running loops number by "UP" "DOWN"

If continuing pressing "SETUP", it will show SFXx, Fdxx, FSxx, then you can set the value for speed, fading and flash by "UP" "DOWN"

3. DMX mode

You can control the devices individually via your DMX-controller. Press "MODE" button until it shows **dH 1**, this means DMX address is 001, you can set the DMX address by "UP" and "DOWN" buttons. If press "SETUP" button, it will show d-p1, it means the device is in which DMX mode 1. You can switch these DMX modes by "UP" and "DOWN" buttons. There are 6 DMX modes.

DMX value as follows:

DMX mode1: d-P1

CHI	CH2	CH3
R	G	B
0-255 dimming	0-255 dimming	0-255 dimming

DMX mode2: d-P2

CHI	CH2	CH3	CH4
R	G	B	Master dimmer
0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming

DMX mode3: d-P3

CHI	CH2	CH3	CH4	CH5	CH6	CH7
R	G	B	R	G	B	R
0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming
CH8	CH9	CH10	CH11	CH12	CH13	CH14
G	B	R	G	B	flash	Master dimmer
0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 flash frequency	0-255 dimming

DMX mode4: d-P4

CHI	CH2	CH3	CH4	CH5	CH6	CH7	CH8	CH9
R	G	B	R	G	B	R	G	B
0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming
CH10	CH11	CH12	CH13	CH14	CH15	CH16	CH17	CH18
R	G	B	R	G	B	R	G	B
0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming
CH19	CH20	CH21	CH22	CH23	CH24	CH25	CH26	
R	G	B	R	G	B	flash	Master dimmer	
0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	0-255 flash	0-255 Light 0-OFF	

DMX modes: d-P5 *

CHI			CH2	
NO.	DMX value	FUNCTION	SPEED	
1	0-7	OFF	Value=0 OFF	
2	8-15	red		
3	16-23	Yellow		
4	24-31	Green		
5	32-39	Cyan		
6	40-47	Blue		
7	48-55	Purple		
8	56-63	White		
9	64-71	PROGRAM02		
10	72-79	PROGRAM03		
11	80-87	PROGRAM04		
12	88-95	PROGRAM05		
13	96-103	PROGRAM06		
14	104-111	PROGRAM07		
15	112-119	PROGRAM08		
16	120-127	PROGRAM09		
17	128-135	PROGRAM10		
18	136-143	PROGRAM11		
19	144-151	PROGRAM12		
20	152-159	PROGRAM13		
21	160-167	PROGRAM14		
22	168-175	PROGRAM15		
23	176-183	PROGRAM16		
24	184-191	PROGRAM17		
25	192-199	PROGRAM18		
26	200-207	PROGRAM19		
27	208-215	PROGRAM20		
28	216-223	PROGRAM21		
29	224-231	PROGRAM22		
30	232-255	Sound Mode	Sensitivity 0-255	

DMX mode6: d-P6

CH1	CH2	CH3	CH4			CH5	CH6	CH7
R	G	B	NO.	DMX value	FUNCTION	SPEED	FLASH	Master dimmer
0-255 dimming 0=OFF	0-255 dimming 0=OFF	0-255 dimming 0=OFF	1	0-7	OFF	NO USE SPEED 0-255	NO USE FLASH 0-255	0-255 dimming (0 = OFF)
			2	8-15	red			
			3	16-23	Yellow			
			4	24-31	Green			
			5	32-39	Cyan			
			6	40-47	Blue			
			7	48-55	Purple			
			8	56-63	White			
			9	64-71	PROGRAM02			
			10	72-79	PROGRAM03			
			11	80-87	PROGRAM04			

			12	88-95	PROGRAM05		
			13	96-103	PROGRAM06		
			14	104-111	PROGRAM07		
			15	112-119	PROGRAM08		
			16	120-127	PROGRAM09		
			17	128-135	PROGRAM10		
			18	136-143	PROGRAM11		
			19	144-151	PROGRAM12		
			20	152-159	PROGRAM13		
			21	160-167	PROGRAM14		
			22	168-175	PROGRAM15		
			23	176-183	PROGRAM16		
			24	184-191	PROGRAM17		
			25	192-199	PROGRAM18		
			26	200-207	PROGRAM19		
			27	208-215	PROGRAM20		
			28	216-223	PROGRAM21		
			29	224-231	PROGRAM22		
			30	232-255	Sound Mode	Sensitivity 0-255	

4. Slave mode

Press "MODE" button to select SLAV to run the slave mode.

5. Sound active mode

Press "MODE" button to select SU31 to be run, now if activated one time, it will run one step, adjust the sensitivity by "UP" and "DOWN" buttons.

Sensitivity: SU01-SU31

6. Static color mode

Press "MODE" button to select Colr to be run, press "SETUP", it will show r/G/b255, then you can adjust the colors by "UP" and "DOWN" buttons.

