DMX **CONTROL** MODE:

7 CHANNEL MODE		
CHANNEL	**VALUE**	**FUNCTION**
CH1	000 - 255	Master dimmer (0-100 %)
CH2	000 - 255	Strobe (0-100%)
CH3	000 - 255	RED (0-100%)
CH4	000 - 255	GREEN (0-100%)
CH5	000 - 255	BLUE (0-100%)
CH6	000 - 255	WHITE (0-100%)
CH7	001 - 004 005 - 080 081 - 150 151 - 220 221 - 255	Blackout Colour Macro Colour Jumping Colour Fading Sound Control

DAISY CHAIN CONNECTION

1) Connect the (male) 3 pin connector side of the DMX cable to the output (female) 3 pin connector of the first fixture
2) Connect the end of the cable coming from the first fixture which will have a (female) 3 pin connector to the input connector of the next fixture consisting of a (male) 3 pin connector. Proceed to connect from the output as stated above to the input of the following fixture and so on.

SPECIFICATIONS:

LED MINI QUAD PAR CAN 8 W WEIGHT & DIMENSIONS (WITHOUT BRACKET)	
Length	186 mm
Width	168 mm
Height	183 mm
Weight	2.0 kg
Beam angle	25 °
POWER	
Power consumption	59 W
AC input	100 V AC - 250 V AC / 50 Hz - 60 Hz
FUSE	
Main	F2A, 250V
CONTROL & PROGRAMMING	
Data input	3-pin XLR male socket
Data output	Locking 3-pin XLR female socket
Protocols	DMX-512 USITT
DMX channel modes	2 CH, 3 CH1, 3 CH2, 4 CH, 7 CH